



The secret of love

CHIVEN 2 | Masturbator



A great sex experience like the best meal, always makes people unforgettable. OTOUCH offers the best ingredients for you, and the rest is up to you.

----- OTOUCH

Visit the following link to know more about OTOUCH brand.

<https://otouchtoys.com>

Content

- 1. Introduction*
- 2. Packing List*
- 3. Specifications*
- 4. Before Use*
- 5. How to Use*
- 6. After Use*
- 7. Disposal*
- 8. Health and Safety Precautions*
- 9. Aftercare & help*

1. Introduction

Thanks for using OTOUCH products! For better use of the product, please read these directions carefully.



2. Packing List

CHIVEN 2	1 pc
USB Charging Cable	1 pc
Storage Pouch	1 pc
Manual	1 pc

3. Specifications

Materials	Silicone, ABS
Vibration Mode	6 frequencies, 3 level
Heating Mode	$35 \pm 3^{\circ}\text{C}$ / $\sim 43 \pm 3^{\circ}\text{C}$
Working Voltage	3.7V
Waterproof Performance	IPX6
Working Noise	<60 dB
Battery Capacity	1000 mA
User Time	> 60 minutes

4. Before Use

- 1) Charge before the first time use, plug the USB charging cable into the charge hole and connect the other end to computer or cellphone. The indicator light will blink regularly when incorrect charge and will keep lighting when fully charged.
- 2) Clean before use, rinse with warm water or mild detergent, dry with a towel.
- 3) Lubricant the product for a more pleasurable experience.

5. How to use

Vibration Function:

- 1) Pressing 2 seconds to turn on/off, single-click to switching mode.
- 2) Press + to increase strength, press – to reduce strength.

Heating Function:

- 1) Pressing 2 second to turn on/off the heating mode.
- 2) Single press to switching temperature. When the indicator light flashes it means heating is under low level when indicator light lights constantly it means heating is under the high level.

6. After Use

- 1) After use, rinse with warm water and sterilized soap, dry with a towel.
- 2) Avoid direct sunshine and keep out of reach of children.

7. Disposal

Disposal of old electronic devices (applicable in the EU and other European countries with separate waste collection systems): The crossed-out dustbin symbol indicates that this pleasure object should not be treated as household refuse, rather be brought to appropriate collection point for the recycling of electronic devices.

8. Health and Safety Precautions

- Do not charge near water.
- Do not charge if the USB cord appears damaged.
- Do not use other USB cords with your product.
- Do not put the product in the dishwasher or microwave, it will damage your product.
- This product is sold as a novelty only. It is not intended for medical applications or any use that has an adverse effect on any function of the body.
- To avoid injury or aggravation of pre-existing physical conditions, this device should not be used on swollen or inflamed areas of skin.
- Wash before and after use.
- Do not share with other sexual partners.
- Never let children play with this product.
- In case of pregnancy, diabetes or illness, consult your physician before use.
- Only use a water-based lubricant with this product, as silicone-based lubricants have been known to damage silicone products.

9. Aftercare & help

If you have any further problems or issues with using your device, do not hesitate to contact our customer service team. Our team is there for your support, to solve your problems as soon as possible. We try to answer all questions within 24 hours of receiving them.

<https://otouchtoys.com>

info@otouchtoys.com

+86 18124015523

Opening hours are: Mon-Saturday, 8 AM -7 PM Beijing Time.